SERENE

USER'S MANUAL

Real Time Baby Sound Sensor



Operating Guide

Thank you for purchasing this product, please read before use (Keep this manual for future reference)

Model CA-BX is an optional accessory for the **CentralAlert**™ Visual Alert System. It is a wireless audio sensor for monitoring real-time baby sounds. Any loud baby sound triggers Model CA-BX to send a wireless signal to all **CentralAlert**™ units. Each unit activates its own speaker, flasher, bed-shaker, and an appropriate icon for alerting. A 3-position sensitivity slide switch is provided for optimal setting.

Model CA-BX offers a realtime response. This means all **CentralAlert**™ functions stop immediately, almost as soon as the baby stops crying. This minimizes continuous false triggering.

Install batteries:

- . Install two AA size alkaline batteries (user provided) and then turn on its power.
- 2. Verify that the (red) **TRANSMIT** indicator blinks when the **TEST** button is pressed.
- 3. Verify Room Noise indicators monitor room noise level.
- 4. This indicates the unit is normal.

Registering Model CA-BX:

This optional accessory must be learned by a Master-Unit in order to work with the system.

1. Press and hold the "SOS/Test" button on the Master-Unit for about 5 seconds to set it to the Learn mode. The digital display

- shows "**LEAr**." (Time **SET** switch must be on **RUN** position)
- Press and hold the "TEST" button on Model CA-BX for about 5 seconds until the Master-Unit beeps. (Speaker must be ON)
- Registration is now complete.
 Press the "SNOOZE / RESET"
 button on the Master-Unit to end
 the Learn mode.

Testing:


- 1. Press the "**TEST**" button on Model CA-BX.
- Confirm that CentralAlert™
 activates all alerting outputs in response.

Installation:

1. Place Model CA-BX on a stable

- surface near the baby so that its microphone port is pointing toward the baby (about 2-5 feet away).
- 2. Set its sensitivity switch so that normal room noise only triggers 1 or 2 indicators.
- When room noise level or baby's crying reaches the fourth indicator, TRANSMIT indicator blinks

 sending a wireless signal to
 - activate all CentralAlert™ units. 5. Batt



Specifications:

- . Advanced Technology: 2.4 Ghz Smart-Code
- 2. Operating range: Up to 200 ft, open space actual distance varies according to house construction.
- 3. Up to 3 Model CA-BX's are supported
- 4. Battery type: Two AA size alkaline
- 5. Battery life: up to 10 months
- 6. Operating temperature: +10 to +30°C
- 7. Size: 2.5" x 3.8" x 1" Wt: 4 Oz
- 8. Spec is subject to change